

TECHNICAL DATA

# Fluke TPS Clamp 10 A/1 A Clip-on Current Transformer



## Specifications: Fluke TPS Clamp 10 A/1 A Clip-on Current Transformer

General Specifications	
Measuring Range selectable per software	0.01 A to 1 A 0.1 A to 10 A
Peak current for sinusoidal currents	3.7 A 37 A
Intrinsic error	0.5%
Frequency Range	40 Hz to 10 kHz
Operating Voltage	300 V CAT IV
Phase Error	0.5°
Jaw Opening	15 mm diameter or 15 x 17 mm bus bars
Errors in % of measuring range at 23°C ± 2 K; 74°F ± 2 K, for 48 to 65 Hz Phase angle error at nominal current I <sub>max</sub> maximum current without time limit (for ac and dc shunts)	

## Ordering information



### **Fluke TPS Clamp 10A/1A**

Clip-on Current Transformer

---

**Fluke.** *Keeping your world up and running.®*

**Fluke (UK) Ltd.**  
52 Hurricane Way  
Norwich, Norfolk  
NR6 6JB  
United Kingdom  
Tel.: +44 (0)20 7942 0708  
E-mail: [cs.uk@fluke.com](mailto:cs.uk@fluke.com)  
[www.fluke.com](http://www.fluke.com)

©2021 Fluke Corporation. All rights reserved.  
Data subject to alteration without notice.  
12/2021

**Modification of this document is not permitted  
without written permission from Fluke Corporation.**