

Fluke TPS Clamp 200 A/20 A Clip-on Current Transformer



Specifications: Fluke TPS Clamp 200 A/20 A Clip-on Current Transformer

General Specifications	
Measuring Range selectable per software	0.2 A to 20 A 2 A to 200 A
Peak current for sinusoidal currents	74 A 300 A
Intrinsic error	0.5%
Frequency Range	40 Hz to 10 kHz
Operating Voltage	300 V CAT IV
Phase Error	0.5°
Jaw Opening	< 15 mm diameter or 15 x 17 mm bus bars
Errors in % of measuring range at 23 °C ± 2 K; 74 °F ± 2 K, for 48 to 65 Hz Phase angle error at nominal current I _{max} maximum current without time limit (for AC and DC shunts)	

Ordering information



Fluke TPS CLAMP 200A/20A

200 A / 20 A Clip-on Current Transformer

Fluke. *Keeping your world up and running.®*

Fluke (UK) Ltd.
52 Hurricane Way
Norwich, Norfolk
NR6 6JB
United Kingdom
Tel.: +44 (0)20 7942 0708
E-mail: cs.uk@fluke.com
www.fluke.com

©2021 Fluke Corporation. All rights reserved.
Data subject to alteration without notice.
11/2021

**Modification of this document is not permitted
without written permission from Fluke Corporation.**