


TECHNICAL DATA

Fluke BCR Zero ohm Calibration Resistor



Product overview: Fluke BCR Zero ohm Calibration Resistor

Zero ohm calibration resistor for Fluke 500 Series Battery Analyzers for performing automated zero calibrations for all function ranges. A zero calibration is required each time a test probe is replaced.

Ordering information



Fluke BCR

Zero ohm Calibration Resistor

Fluke. *Keeping your world up and running.®*

Fluke Corporation

PO Box 9090, Everett, WA 98206 U.S.A.

For more information call:

In the U.S.A. (800) 443-5853

In Europe/M-East/Africa +31 (0)40 267 5100

In Canada (800)-36-FLUKE

From other countries +1 (425) 446-5500

Fluke Electronics (Malaysia) Sdn Bhd

Suite D-3A-4, Block D

SouthGage Commercial Centre, No2

Jalan Dua Off Jln Chan Sow Lin

55200 KL

Malaysia

Email: info.asean@fluke.com

www.fluke.com/my

©2021 Fluke Corporation. Specifications subject to change without notice.

12/2021

Modification of this document is not permitted without written permission from Fluke Corporation.