

Fluke TPS Clamp 200 A/20 A Clip-on Current Transformer



Specifications: Fluke TPS Clamp 200 A/20 A Clip-on Current Transformer

General Specifications	
Measuring Range selectable per software	0.2 A to 20 A 2 A to 200 A
Peak current for sinusoidal currents	74 A 300 A
Intrinsic error	0.5%
Frequency Range	40 Hz to 10 kHz
Operating Voltage	300 V CAT IV
Phase Error	0.5°
Jaw Opening	< 15 mm diameter or 15 x 17 mm bus bars
Errors in % of measuring range at 23 °C ± 2 K; 74 °F ± 2 K, for 48 to 65 Hz Phase angle error at nominal current I _{max} maximum current without time limit (for AC and DC shunts)	

Ordering information



Fluke TPS CLAMP 200A/20A

200 A / 20 A Clip-on Current Transformer

Fluke. *Keeping your world up and running.®*

Fluke Corporation
PO Box 9090, Everett, WA 98206 U.S.A.

For more information call:
In the U.S.A. (800) 443-5853
In Canada (800) 36-FLUKE
From other countries +1 (425) 446-5500
www.fluke.com

©2021 Fluke Corporation.
Specifications subject to change without notice.
12/2021

**Modification of this document is not permitted
without written permission from Fluke Corporation.**