

# Fluke TPS FLEX 36 Flexible Current Probe



## Specifications: Fluke TPS FLEX 36 Flexible Current Probe

General Specifications	
Measuring Range selectable per software	30 A to 3000 A
	60 A to 6000 A
Peak current for sinusoidal currents	10 kA
	19 kA
Intrinsic error	1%
Frequency Range	45 Hz to 3.0 kHz
Operating Voltage	300 V CAT IV
Phase Error	0.5°
Jaw Opening	91 cm length
	4 m cable
Errors in % of measuring range at 23°C ± 2 K; 74°F ± 2 K, for 48 to 65 Hz Phase angle error at nominal current I <sub>max</sub> maximum current without time limit (for AC and DC shunts)	

## Ordering information



**Fluke TPS FLEX 36**

---

**Fluke.** *Keeping your world up and running.®*

**Fluke Corporation**  
PO Box 9090, Everett, WA 98206 U.S.A.

**For more information call:**  
In the U.S.A. (800) 443-5853  
In Canada (800) 36-FLUKE  
From other countries +1 (425) 446-5500  
[www.fluke.com](http://www.fluke.com)

©2021 Fluke Corporation.  
Specifications subject to change without notice.  
12/2021

**Modification of this document is not permitted  
without written permission from Fluke Corporation.**