

## TECHNICAL DATA

# PLS 6R Replacement Window Glass Insert



## Key features

- Broken laser level glass? No need to buy a new laser.
- Minimize job site delays by using this quick in-field windows replacement.
- Replacement glass only for the PLS 6R red combination point and cross line laser.
- Replace damaged glass on your PLS laser affixed with just five screws.
- Please ensure your laser is operating and accurate before swapping glass inserts.

## Product overview: PLS 6R Replacement Window Glass Insert

PLS® Laser Levels are durable professional-grade tools that are made for reliability in harsh construction environments, but even the most rugged laser level can have its glass broken when dropped from a high enough distance. To keep contractors on schedule, Pacific Laser Systems, a Fluke company, introduces PLS Laser Level Replacement Glass Inserts, new housing glass inserts that offer a quick in-field solution to broken laser level glass.

With the new PLS HGI glass inserts, contractors can replace broken glass on their PLS laser levels on-site using a Phillips-head screwdriver, eliminating the need to take the laser level in for repair.

The glass inserts are available for PLS models 3R, 3G, 5R, 5G, 6R, 6G, 180R, and 180G.

## Ordering information



### **PLS-HGI6R**

PLS HOUSING GLASS INSERT FOR PLS 6R

---

**Fluke.** *Keeping your world up and running.®*

**Fluke Corporation**  
PO Box 9090, Everett, WA 98206 U.S.A.

**For more information call:**  
In the U.S.A. (800) 443-5853  
In Canada (800) 36-FLUKE  
From other countries +1 (425) 446-5500  
[www.fluke.com](http://www.fluke.com)

©2021 Fluke Corporation.  
Specifications subject to change without notice.  
12/2021

**Modification of this document is not permitted  
without written permission from Fluke Corporation.**