

Data teknis

Fluke BTL-A Voltage/Current Probe Adapter



Ikhtisar Produk: Fluke BTL-A Voltage/Current Probe Adapter

Adaptor probe voltase/arus untuk Fluke 500 Series Battery Analyzer. BTL-A memungkinkan koneksi probe tes banana plug 4 mm standar atau adaptor clamp arus. Memungkinkan BT521 Series Battery Analyzer untuk melakukan pengukuran arus dan voltase AC dan DC dengan menggunakan Fluke i410 AC/DC Current Clamp.

Model



Fluke BTL-A

Voltage/Current Probe Adapter

Fluke. *Memastikan aktivitas Anda terus berjalan dan beroperasi.*

Fluke Corporation

PO Box 9090, Everett, WA 98206 U.S.A.

For more information call:

In the U.S.A. (800) 443-5853

In Europe/M-East/Africa

+31 (0)40 267 5100

In Canada (800)-36-FLUKE

From other countries +1 (425) 446-5500

www.fluke.com

BUT. FLUKE SOUTH EAST ASIA PTE LTD

Menera Satu Sentra Kelapa Gading #06-05

Jl. Bulevar Kelapa Gading Kav. LA# No. 1

Summarecon Kelapa Gading

Jakarta Utara 14240

Indonesia

Tel: +62 21 2938 5922

Email: info.asean@fluke.com

www.fluke.com/id

©2021 Fluke Corporation. Specifications subject to change without notice.

12/2021

Modification of this document is not permitted without written permission from Fluke Corporation.