

Datos técnicos

Kit y puntas de prueba con fusible FTP y FTPL SureGrip™



Características principales

- Built-in fuses for additional measurement protection
- Probes allow indication of live voltage even with blown fuse, helping to prevent the user from thinking no voltage is present
- 2 mm threaded probe tips include removable 4 mm lantern-style spring contacts and removable GS38 insulated IC caps for probing closely spaced leads
- Operating temperature – 20°C to 50°C (-5°F to 120°F)
- CAT III 1000 V, CAT IV 600 V, 10 A rating

Descripción general del producto: Kit y puntas de prueba con fusible FTP y FTPL SureGrip™

In response to new ESA guidelines, Fluke introduces test probes with built-in fuses for additional measurement protection. And, if the probe fuse does blow, these probes will still allow the meter to indicate live voltage helping to prevent a possible misreading of no voltage present. The new modular FTP probes can mount onto any Fluke modular lead format. Rated to CAT III 1000 V, these probes also have removable sheathed tips for additional safety.

Especificaciones: Kit y puntas de prueba con fusible FTP y FTPL SureGrip™

- Probes allow indication of live voltage even with blown fuse for added security¹
- Built-in 1000 V, 11 A fuses with 20 kA interrupt rating
- 2 mm threaded probe tips include removable 4 mm lantern-style spring contacts and removable GS38 insulated IC caps for probing closely spaced leads
- Operating temperature -20°C to 50°C (-5°F to 120°F)
- CAT III 1000 V, CAT IV 600 V, 10 A rating, Pollution Degree 2
- Recommended for use with Fluke modular TL224 SureGrip™ silicone test leads and compatible with most modular test leads
- Replace fuse by unscrewing probe handle at finger guard. Use only Fluke fuse part number 803293
- Current mode is non-functional with blown fuse

1. Voltage readings with blown fuse are approximate and vary with the meter impedance. Before and after each measurement, verify presence of blown fuse by checking continuity of the fused test probe. See explanation below under "DMM Input Impedance." Current mode is non-functional with blown fuse.

Modelos



Fluke FTP

Fluke FTP SureGrip™ Fused Test Probes

Fluke. Manteniendo su mundo en marcha.

Fluke Corporation
Everett, WA 98206 EE.UU.

Para obtener información adicional En EE. UU. (800) 443-5853

En Europa/Medio Oriente/África
+31 (0)40 267 5100

En Canadá (800)-36-FLUKE
www.fluke.com

Latin America
Tel: +1 (425) 446-5500
www.fluke.com/es-gt

©2022 Fluke Corporation. Reservados todos los derechos. Impreso en los Países Bajos. Información sujeta a modificación sin previo aviso.
01/2022

No está permitido modificar este documento sin autorización por escrito de Fluke Corporation.